

CAPISCO LTD

INSTALLATION INSTRUCTIONS



WEAR GLOVES

Always use clean gloves when handling metal surfaces to avoid finger marks.



STORE MATERIAL INDOORS

Wrapped patinated material should only be stored in an internal location. Wrapped work should never be stored outdoors, as moisture can collect and will leave marks.



PLACE FACE DOWN ON DRY, CLEAN SURFACES WITH PROTECTION

Place all metalwork work onto a clean, smooth and non-marking surface.



NO ADHESIVE TAPE

Never use adhesive tape, low tack tape or stick notices onto the patinated surface. The adhesive cannot be removed from the surface without professional cleaning.



CLAMPING PATINATED WORK

Never directly clamp onto the patinated face. Place clean, soft, non-marking material between the patinated surface and the clamp.



LIQUIDS ON A PATINATED SURFACE

If the patination gets wet during installation, please dry immediately using a clean, soft cloth. Moisture should not be left to dry naturally on the surface.



DON'T USE KNIVES OR SHARP TOOLS ON A PATINATED SURFACE

Sharp tools will scratch and damage the surface and cause permanent damage.



CLEANING INSTRUCTIONS

Only use a soft dry cloth to clean the surface.

Never use any cleaning products, polishes, abrasive pastes or pads on a patinated surface. Chemical cleaners will remove the wax and damage the patina.



PROTECTING INSTALLED PATINATION WORK

Never tape protection directly onto the patinated surface. Clean, soft non-marking wrapping should be used. Never use bubble wrap as this will leave circular marks.

ANY ISSUES CALL +44 (0)20 85328838 OR EMAIL WORKS@PATINATION.COM WITH PHOTOGRAPHS.